DHHS, NIH, ORF and ORS

NIH Waste Disposal Guide at Bayview Campus

Version: NIA IRP Baltimore BRC and Triad Buildings



FIRE or Police Emergency - Call 911 or 9-911

Chemical/Biological Spills - Contact NIA Safety at (410) 558-8636

NIAIRPBaltimoreSafetyOffice@mail.nih.gov

Up to date information can be found at: http://orf.od.nih.gov/EnvironmentalProtection/WasteDisposal

Chemical Waste

For Waste Minimization and Pollution Prevention guidance go to: http://orf.od.nih.gov/EnvironmentalProtection/WasteDisposal/Pages/chemicalwaste.aspx

Nonradioactive chemical solids, liquids, gases, or other waste types contaminated with hazardous chemicals.

Examples of Chemical Waste

- Non-radioactive lead shielding and lead scrap
- Chemical reagents, all types
- Oil, all types
- Batteries, all types
- Sodium vapor and HID lamps

- Photographic film processing solutions and x-ray film
- Mercury containing items (thermometers, batteries, UV lamps, etc.)
- Cytotoxic agents & prescription drugs (non-controlled substances)
- Non-returnable gas cylinders and lecture bottles (18-inch length maximum)
- Agarose gels contaminated with ethidium bromide, acrylamide or other contaminants
- Fluorescent light tubes and bulbs

Tag and Identify

General Information

- Use Chemical Waste Tag (NSN-7530-00-L07-5985) from the Self-Service Store/NIH Stock Supply Catalog
- Identify all major consituents and hazardous components by chemical name
- Don't use acronym or brand name
- Complete information on front and back of tag as soon as the first drop of waste is added to the container.
- IC's are responsible for the purchase of the Chemical waste tags
- Generators name, phone number and date
- Building & room number and IC
- All major chemical constituents

This **must** occur with chemicals in the Satellite Accumulation Area(s) (SAA).

The property of the control of the c

Don't Mix

- Mercury or mercury containing materials with any other waste
- Dioxin or dioxin containing materials with any other waste
- Peroxide forming chemicals with any other waste
- Oxidizing agents with organic compounds, flammable, and combustible materials.
- Oxidizing agents with reducing agents (e.g. zinc, alkaline metals)
- Aqueous wastes with organic solvents
- Acids with: Organic, flammable and combustible materials basic (caustics) and reactive metals such as sodium, magnesium and potassium chemicals which can generate toxic gases upon contact such as sodium cyanide, iron sulfide, azides, and phosphides

For additional information on chemical segregation go to:http://orf.od.nih.gov/Environmental+Protection/Waste+Disposal/chemicalwaste.htm

• Store in laboratory while awaiting pick-up.

DO NOT PUT WASTE CONTAINERS IN HALLWAYS OR OTHER PUBLIC LOCATIONS DO NOT TRANSPORT WASTE ACROSS HALLWAY TO ANOTHER LOCATION FOR STORAGE

- Ensure that all chemical waste containers are closed securely except at the time waste is added
- Use NIH approved funnels with lids. Close the lid when not adding waste to the container
- Place liquid waste containers in secondary containment pan(s)
- Do not fill containers over the indicated fill line
- Keep exterior surface of containers free of contamination
- Chemical waste MUST be picked up within 60 days of the accumulation start date
- Discarding chemical waste via sinks, in MPW boxes, or trash bins and dumpster
- Discarding radioactive materials, oxidizers, heavy metals, phenols, acids, and bases in flammable solvent safety cans
- Treating chemical waste in any manner
- Evaporating volatile chemicals in laboratory spaces or chemical hoods
- NIH seeks to support Federal incentives to restrict the purchase and use of specific toxic chemicals by employing sound waste minimization techniques and affirmative procurement strategies. For toxic chemical reduction strategies go to: http://nems.nih.gov/Pages/default.aspx
- Before purchasing new chemicals check out NIH's free surplus chemicals inventory.
- For the surplus chemical inventory go to NIH FreeStuff website: http://stuff.nih.gov/Home.aspx
- Contact DEP (301) 496-7990 for information on NIH's solvent recycling program
- Chemical waste supplies (funnels, waste tags, carboys, etc.) may be obtained by contacting Chemical Safety Tech (410) 558-8413



Prohibited Waste Management Practices in Laboratories

Waste Minimization & Toxic Chemicals Reduction

Chemical Waste Supplies





Chemical Waste Collected in Empty Chemical Bottles

Multiple Containers of Chemical Waste



Larger Volumes of

Flammable Liquids



Waste Management Procedures

- Empty chemical bottles may be used to collect small quantities of chemical waste
- Cross out original label and affix a new label or use a chemical waste tag indicating contents (compounds, concentration, and accumulation start date)
- A completed chemical waste tag is required for each bottle prior to pick-up by the Chemical Waste Service



- Multiple containers of compatible chemicals may be placed in a single box for disposal
- The contents of each container must be identified
 - For chemical waste that is in its original container write the word "WASTE" on the bottle and the date
 - For chemical waste that is not in its original container complete and attach a chemical waste tag
 - Compatible materials in its original containers can be placed into an empty box with a chemical waste tag attached to the box. Complete generator information and certification
- Do not stack chemical containers on top of one another
- Do not seal box
- Chemicals waste containers (3 or 5 Gal) can be requested from Chemical Waste Services



- Combine only compatible chemicals in a container. For information on chemical compatibility go to: http://orf.od.nih.gov/EnvironmentalProtection/WasteDisposal/Pages/chem_compat.aspx
- Examples of waste that can be placed in these containers include formalin, phenol, chloroform, and aqueous liquids with trace organics. For more information on what goes in these containers go to:
 http://orf.od.nih.gov/EnvironmentalProtection/WasteDisposal/Pages/chemicalwaste.aspx
- Complete and attach a Chemical Waste Tag to the container when the first waste is added to the container
- Place the DATE on the tag at the start of waste accumulation
- Record on the Chemical Waste Tag each chemical added to the container and its concentration and volume
- Store waste containers in secondary containment pans away from ignition and heat sources



- Use only the safety carboys provided by the Chemical Disposal Service, (410) 558-8413
- Complete and attach a Chemical Waste Tag to the container when the first waste is added to the container
- Record on the Chemical Waste Tag each chemical added to the container and the concentration or volume
- Examples of waste that can be placed in these containers include DNA/HPLC wastes, alcohols, xylenes, acetonitrile and organic solvents
- Contents of safety carboy should not exceed "fill" line on the carboy
- HPLC users can request containers with special fittings to connect to the HPLC machine, (301) 496-4710
- Do not place radioactive materials, inorganic/organic acids, bases or metallic compounds in these containers
- Store waste containers in secondary containment pans away from ignition and heat sources



•DO NOT PLACE radioactive materials, infectious wastes, liquids, sharps or broken glass with this waste

- Place materials in a clear plastic bag (medium: NSN-8105-01-195-8730; large: NSN-8105-00-826-6468)
- Close plastic bag with filament tape or bag closure tie
- Place bag in a plain cardboard box or double bag the dry waste
- Complete and attach a completed Chemical Waste Tag
- Examples of this type of waste: contaminated gloves, pipette tips, absorbent paper, and disposable labcoats

Continued on next page



Chemical Waste

Chemically Contaminated Agarose Gels

Explosive/Reactive Chemicals

Disposal of Narcotics and Controlled Substances

Laboratory Moves - Transferring Chemicals

Empty Chemical Bottles

Formalin/Aldehyde Solutions with Tissue, Human and Animal Parts

Batteries

Procurement, Use and Disposal of Mercury and its Compounds

- Gel contaminated with ethidium bromide, or other stains must be collected as chemical waste
- Do not dispose of gels in MPW boxes
- Gels can be collected in a lined box or 5 gallon pail with liner
- To order a 5 gallon pail container call the Chemical Waste Service, (410) 558-8413
- Collection containers must not contain any free liquids
- Complete and attach a Chemical Waste Tag to the container. Identify gel types and contaminents



- STORE SAFELY in accordance with manufacturer's instructions
- For explosive/reactive chemicals that appear unstable/compromised call NIA Safety Office at, (410) 558-8636. immediately for guidance
- Examples of explosive/reactive chemicals include perioxidized ethers, dry picric acid, organic peroxides, peroxy acids, polynitro compounds, hydrides of sodium lithium and alkali metals.

For more examples go to: http://orf.od.nih.gov/EnvironmentalProtection/WasteDisposal/Pages/chemicalwaste.aspx

- Contact NIA Controlled Substance Custodian, Alfred May at (410)558-8574, with assistance with the disposal of narcotics and controlled substance
- Contact NIA Safety Office manager for guidance assistance at, (410) 558-8636.
- Laboratories are responsible for procuring this service from approved vendors if DEP is unable to complete the move due to a large volume of chemicals.

For more information go to: http://orf.od.nih.gov/EnvironmentalProtection/WasteDisposal/Pages/chemicalwaste.aspx

- All empty bottles (glass, plastic and metal) that previously contained chemicals (liquid, solid), buffer saline solutions can be recycled if collected by the Chemical Waste Services). Leave cap on empty bottles
- Call Chemical Waste Services to request collection totes for the empty bottles
- Empty bottles and totes are to be stored in labs prior to pickups
- Empty bottles that previously contained infectious or radioactive material are **not** acceptable for recycling
- Empty bottles can also be reused to collect small quantities of chemical waste. (See Waste Management Procedures)
- Do not place empty chemical bottles into or around commingled recycling bins or "Disposable Labware & Broken Glass" containers.

Formalin/Aldehyde solutions containing tissue, human and animal parts can be disposed of by:

- Separate the tissue from the formalin or formaldehyde solution; dispose of the liquid through chemical disposal service; dispose of the tissue in **MPW box**. (See **MPW Section**)
- All battery types may be placed in BRC 2B205 for disposal/recycling
- For assistance, call Chemical Safety Tech (410) 558-8413
- UPS (uninterruptible power source) batteries must be removed from the UPS casing prior to pick-up. Call the Chemical Safety Technician for disposal, (410) 558-8413
- All batteries must be collected for recycling by the Chemical Waste Service, including non-UPS batteries internal to equipment
- Examples are alkaline, all rechargeable batteries, lithium, lead-acid and all other types
- Purchase and use of mercury and its compounds prohibited in accordance with NIH Mercury Policy (Manual Chapter 3033)
 for information on NIH Mercury Policy go to: http://oma.od.nih.gov/manualchapters/intramural/3033/
- Exceptions to the prohibition on procurement and use may be granted for limited scientific and medical uses of mercury or mercury compounds for which there are no acceptable alternatives
- To receive exception approval to procure and/or use mercury, NIH Form 2936 must be completed and submitted to the following pittj@mail.nih.gov; FloydW@mail.nih.gov and promj@ors.od.nih.gov.
- For information on NIH's Mercury Abatement Program go to: http://orf.od.nih.gov/EnvironmentalProtection/MercuryFree/
- Pages/NIH-Mercury-Hazard-Reduction-Campaign.aspx
- Mercury and mercury containing equipment must be managed as chemical waste, call the Chemical Safety Technician for pickup (410) 558-8413.

Multihazardous Waste

(Containing Radioactive Materials)

Multihazardous waste is waste containing two or more of the following: radioactive material, infectious agent(s), or hazardous chemical(s). One type of multihazardous waste is Mixed Waste: waste that contains both a hazardous chemical component and radioactive material regulated by the NRC. "Mixed Waste" is a subset of multihazardous waste For Waste Minimization and Pollution Prevention guidance go to: http://orf.od.nih.gov/EnvironmentalProtection/WasteDisposal/Pages/multiwaste.aspx

Examples of Multihazardous Waste

- Aqueous radioactive wastes containing chloroform or heavy metals
- Methanol/acetic acid solutions from electrophoresis procedures containing radioactive material
- Hazardous liquid scintillation counting fluids with radioactive content
- · Radioactive trichloroacetic acid solutions
- Phenol/chloroform mixtures used to extract DNA from radio labeled cells
- Vacuum pump oil contaminated with radioactive material
- Chemical or radioactive wastes containing infectious agents
- Used animal bedding contaminated with at least two of the above listed hazard types (chemical, radioactive and infectious)
- Lead contaminated with radioactive material
- Agueous radioactive liquids with pH <2 or >12.5

General Information

Mixed waste containers (4L, 10L, and 20L) and spill trays are available by calling Radioactive Waste Service at (301) 496-4451. Caution-Radioactive Material labels (NSN-7690-00-833-0318), Radioactive Waste Pick-up Receipts (NSN-7530-00-L07-8835), and Chemical Waste Tags (NSN-7530-00-L07-5985) are available at the Self-Service Store. Call (301) 496-4451 or log on to http://drsportal.ors.od.nih.gov/ to request your mixed waste pick-up.







Avoid Generating

• Avoid generating multihazardous wastes as disposal can be difficult and expensive. For additional assistance in avoiding generation of multihazardous waste, call the Chemical Safety Technician, (410) 558-8413

Minimize Generation Inactivate Waste

- Minimize volumes generated if generation of multihazardous waste cannot be avoided
- PRIOR to beginning work activities which will generate multihazardous waste, call DEP or DRS for waste management information
- Inactivation of the agent(s) is usually the first step in the disposal process if the multihazardous waste contains an infectious agent(s). Contact your Safety Officer at NIAIRPBaltimoreSafetyOffice@mail.nih.gov, for appropriate inactivation methods
- Specific procedures for autoclaving radioactive waste must be approved by your Area Health Physicist prior to use of an autoclave to inactivate the waste. (See Radioactive Waste Section)

Security

• Mixed waste must be secured or held under constant surveillance to prevent unauthorized removal or access. Consult your Area Health Physicist in DRS at (301) 496-5774, for more information

Continued on next page

Multihazardous Waste Pick-up: 301-496-4451 Assistance: 301-496-5774

Multihazardous Waste

Don't Mix

- Liquid mixed waste with solid radioactive waste
- Hazardous chemicals with radioactive aqueous wastes
- Segregate by isotope half-life: very short (<30 days), intermediate (30-120 days), and long (>120 days)
- Flammable liquids with radioactive material
- Radioactive aqueous wastes with high organic content mixed waste
- Infectious agents with non-infectious materials

Identify and Label

- List on the Radioactive Waste Pick-up Receipt an estimate of radionuclide(s) and activity present at time of pick-up
- Record on the Chemical Waste Tag each chemical added to the container and the concentration or volume
- Ensure that all mixed waste containers have a:
 - Caution-Radioactive Material label (NSN-7690-00-833-0318)
 - Radioactive Waste Pick-up Receipt (NSN-7530-00-L07-8835)
 - Chemical Waste Tag (NSN-7530-00-L07-5985)








Shielding Requirements

- Shield radioactive material such that:
 - Radiation levels are less than 2 millirem/hour @ 30 cm within a posted laboratory,
 AND radiation levels are less than 0.5 millirem/hour or will total 50 millirem in a year in any unrestricted area (e.g., space adjacent to a posted laboratory or corridor)
- The Radioactive Waste Service recycles beta/plastic and lead shielding call (301) 496-4451 and inquire if shielding is available

Waste Storage

- Mixed waste containing radioactive material must only be stored in laboratories posted for use of radioactive material
- NEVER place mixed waste in corridors even while awaiting pick-up
- Ensure that all waste containers are closed securely to prevent leaks, spills or escape of vapors
- Mixed waste must be stored in appropriate spill containment trays or devices
- Mixed waste must be picked up within 60 days of the collection start date



Specific Types of Mixed Waste

Liquid Scintillation Vials

- Ensure vials caps are securely tightened
- Place vials in original tray or box (with plastic liner)
- Separate by radionuclide Vials with the same nuclide may be grouped together and H-3 & C-14 may be grouped together
- Attach to tray or box:
 - Caution-Radioactive Material label (NSN-7690-00-833-0318)
 - Radioactive Waste Pick-up Receipt (NSN-7530-00-L07-8835). Add name of Scintillation Cocktail to Pick-up Receipt
 - Chemical Waste Tag (NSN-7530-00-L07-5985)



- Place lead in box and attach:
 - Caution-Radioactive Material label (NSN-7690-00-833-0318)
 - Radioactive Waste Pick-up Receipt (NSN-7530-00-L07-8835)
 - Chemical Waste Tag (NSN-7530-00-L07-5985)



Pick-up: 301-496-4451 Assistance: 301-496-5774

Radioactive Waste

Examples of Radioactive Waste

Radioactive waste is any waste that contains or is contaminated with radioactive material For Waste Minimization and Pollution Prevention guidance go to:

http://orf.od.nih.gov/EnvironmentalProtection/WasteDisposal/Pages/rad procedures.aspx

- Aqueous radioactive solutions
- Liquid scintillation counting fluids and vials (if LSC fluids and vials are flammable, it's "mixed wastes")
- Materials contaminated with radioactive material after inactivation of infectious agents, such as:
 - Animal carcasses and excreta
 - Experimental or spill clean-up materials, absorbent paper, gloves
 - Patient care materials
 - Plastic or glassware

General Information and Assistance

• In the planning stages of your experiment, review disposal procedures with your Area Health Physicist, (301) 496-5774. Radioactive waste containers (stepcan, 2 gallon and 5 gallon carboys) are available by calling Radioactive Waste Service at (301) 496-4451. Radioactive Waste Pick-up Receipts (NSN-7530-00-L07-8835) and Caution-Radioactive Material labels (NSN-7690-00-833-0318) are available at the Self-Service Store. Call (301) 496-4451 or log on to http://drsportal.ors.od.nih.gov/ to request your radioactive waste pick-up.







Security

Don't Mix

Adjust pH

Identify and Label

Shielding Requirements

- Radioactive waste must be secured or held under constant surveillance to prevent unauthorized removal or access
- Source vials, when not in use, must be stored in a locked container at all times
- Consult your Health Area Physicist, (301) 496-5774, for more information
- For access to the Rad safety storage room, please contact the Area Health Physicist for instructions.
- Liquid waste with dry waste
- Short half-life (< 120 days) with long (> 120 days) half-life waste
- Waste containing chloroform or trichloroacetic acid (TCA) with any other aqueous radioactive waste
- Aqueous solutions with mixed wastes
- For mixed wastes see Don't Mix in Multihazardous Waste Section
- Aqueous liquid waste solutions should be adjusted to a pH between 6 and 10. Use caution; Call your Area Health Physicist, (301) 496-5774, for assistance
- List on the Radioactive Waste Pick-up Receipt an estimate of radionuclide(s) and activity present at time of pick-up
- Ensure that all radioactive waste containers have a:
 - Caution-Radioactive Material label (NSN-7690-00-833-0318)
 - Radioactive Waste Pick-up Receipt (NSN-7530-00-L07-8835)





Shield radioactive material such that:

Radiation levels are less than 2 millirem/hour @ 30 cm within a posted laboratory, AND radiation levels are less than 0.5 millirem/hour or will total 50 millirem in a year in any unrestricted area (e.g., space adjacent to a posted laboratory or corridor)

• The Radioactive Waste Service recycles beta/plastic and lead shielding – call (301) 496-4451 and inquire if shielding is available

Waste Storage

- Radioactive waste must only be stored in laboratories posted for use of radioactive material
- NEVER place radioactive waste in corridors-even while awaiting pick-up
- Ensure that all waste containers are closed securely

Aqueous Waste

Waste Management Procedures for Material Contaminated with Radioactive Material

- Do not discard radioactive wastes into sinks drains
- Use plastic carboys available from Radioactive Waste Service, (301) 496-4451
- Contents should NOT exceed the "Fill line" on the container
- Secure the cap of container tightly
- Attach a Radioactive Waste Pick-up Receipt (NSN-7530-00-L07-8835)





Solvents/Other
Hazardous Chemical
Constituents

- Refer to Multihazardous Waste Section
- Use special mixed waste containers available from the Radioactive Waste Service, (301) 496-4451
- Attach a Radioactive Waste Pick-up Receipt (NSN-7530-00-L07-8835) and a Chemical Waste Tag (NSN-7530-00-L07-5985)
- As chemicals are added to the container, record chemical name and amount on the Chemical Waste Tag

Disposable Labware

- Use bench-size Disposable Labware & Broken Glass box (NSN-8115-01-122-1772)
- Use absorbent paper pads for residual liquid in the bottom of the box.
- Close and secure box with filament tape
- Affix Caution-Radioactive Material label (NSN-7690-00-833-0318)
- Attach a Radioactive Waste Pick-up Receipt (NSN-7530-00-L07-8835)

"Sharps" (needles syringes, scalpel blades/razor blades, pipette tips, etc.)

- Place "sharps" in a puncture resistant container: (small: NSN-6530-01-294-2865; or medium: NSN-6530-01-274-5099)
- Fill only 3/4 full, snap lid closed, then place sharps box inside MPW box
- Affix Caution-Radioactive Material label (NSN-7690-00-833-0318)
- Attach a Radioactive Waste Pick-up Receipt (NSN-7530-00-L07-8835)



MPW, Patient Care Materials, Animal Carcasses and/or Tissues, Bedding and/or Solid Excreta With Radionuclides

- MPW boxes, biohazardous bags, clear packing tape and zip ties are located in room 02B207 (BRC) and 1906 (Triad).
- Fold the flaps down on the outside of the box and tape to seal the bottom of the MPW box.
- Place TWO biohazardous bags (one inside the other) into the MPW box and pull the bag tops down over the flaps
- MPW, Patient Care Materials, Animal Carcasses and/or Tissues, Bedding and/or Solid Excreta With Radionuclides-replace "or" with and for the following statement- A filled MPW box should weigh NO MORE than 40 pounds or be no more than 3/4 full (DO NOT OVERFILL)
- Seal each bag SEPARATELY. Twist plastic bag at the top; bend the twisted portion to form a loop and seal using the plastic bag closure tie.
- Fold the flaps to close the MPW and tape the box closed.
- Clearly affix Caution-Radioactive Material label (NSN-7690-00-833-0318) and Radioactive Waste Pick-up Receipt (NSN-7530-00-L07-8835)

NOTE: For animal tissue or carcasses, refrigerate or freeze if held longer than 4 hours; freeze if held more than 24 hours

• The MPW re-supply areas for the BRC & Triad will be replenished weekly. For any additional MPW guidance contact the NIA Safety Technician (410) 558-8411; NIAIRPBaltimoreSafetyOffice@mail.nih.gov.

Continued on next page

Radioactive Waste

Infectious Waste to be Autoclaved

- Contact your Area Health Physicist for guidance on autoclaving radioactive material prior to using an autoclave to process the material
- A Caution Radioactive Material label must be affixed to any autoclave in which radioactive material will be processed
- Use TWO (one inside the other) autoclavable Biohazard bags imprinted with process indicator (small: NSN-6530-01-282-6378; medium: NSN-6530-01-142-2255; large: NSN-6530-01-218-4644)
- Place bags in pan for transporting and autoclaving
- Add 50 ml water to the inner autoclave bag BEFORE closing and seal each bag SEPARATELY with autoclave tape
- Process for 60 minutes at minimum 121° Centigrade
- Cool and affix Caution-Radioactive Material label (NSN-7690-00-833-0318) and Radioactive Waste Pick-up Receipt (NSN-7530-00-L07-8835)
- Specific procedures for autoclaving radioactive waste must be approved by your Area Health Physicist prior to use of an autoclave to inactivate the waste
- Survey the inside of the autoclave for radioactive contamination following use of the autoclave

NOTE: Autoclaves must be maintained to manufacture specification and validated monthly

Lead

Liquid Scintillation Vials

- Lead which contains or is contaminated with radioactive material is a mixed waste see Multihazardous Waste Section
- Vials with hazardous chemical(s) are a mixed waste see Multihazardous Waste Section
- Segregate securely capped vials according to radionuclide H-3 and/or C-14 may be disposed
 of together
- Segregate securely capped vials according to cocktail type
- Place vials in original shipping tray or box trays with the same radionuclide may be grouped together
- Clearly affix Caution-Radioactive Material label (NSN-7690-00-833-0318)
- Attach a Radioactive Waste Pick-up Receipt (NSN-7530-00-L07-8835)



Source Vials

- Empty vials may be disposed of in stepcan as dry solid radioactive waste
- For vials containing radioactive fluid or vials with lead packaging:
 - Place securely capped vials in a small box (with plastic liner)
 - Affix a Caution-Radioactive Material label (NSN-7690-00-833-0318) to the box
 - Attach a Radioactive Waste Pick-up Receipt (NSN-7530-00-L07-8835)



OtherTypes of Dry/ Solid Material

Contaminated Equipment

Survey Instruments

- Use labeled stepcan containers (with liner bags) available from Radioactive Waste Service, (301) 496-4451
- Clearly affix Caution-Radioactive Material label (NSN-7690-00-833-0318)
- Attach a Radioactive Waste Pick-up Receipt (NSN-7530-00-L07-8835)

Call the Radioactive Waste Service, (301) 496-4451, for guidance on disposing contaminated equipment

- Contact your Area Health Physicist to see if your survey instrument can be recycled
- Remove the radioactive source from the side of the instrument and call Radioactive Waste Service at (301) 496-4451 to pick-up the check source. Dispose of the survey meter and accessories through the NIH property management system
- Attach a Radioactive Waste Pick-up Receipt (NSN-7530-00-L07-8835) to the check source
- Contact your Area Health Physicist or visit the DRS website at http://drs.ors.od.nih.gov/policy/equip_clearance.htm
 for guidance on how to surplus Liquid Scintillation or Gamma counters and other laboratory equipment containing internal radioactive sources

Medical Pathological Waste (MPW)

Examples of MPW

For Waste Minimization and Pollution Prevention guidance go to: http://orf.od.nih.gov/EnvironmentalProtection/WasteDisposal/Pages/mpw waste.aspx

- Open MPW containers shall be maintained inside the labs until sealed. Once properly sealed, MPW boxes shall be transported to the NIA Medical Pathological Waste (MPW) Holding Area 02B207 at the BRC and at the loading dock for the Triad.
- Waste containing or contaminated with infectious or pathogenic agent(s)
- Pathological waste includes: Animal carcasses, anatomical waste (organs, tissue from humans or animals)
- Sharps containers (scalpels, razor blades, Pasteur pipettes, pipette tips, all needles and syringes). (See "Sharps" section.)
- Animal bedding contaminated with pathogenic agents which cannot be decontaminated through autoclaving
- Any material potentially contaminated with cytotoxic drug(s): Empty cytotoxic drug vials, cytotoxic drug dispensing apparatus, patient care materials, towels, absorbent material, or similar materials



MPW Contaminated with Radioactive Materials or Hazardous Chemicals

Decontaminate

Disinfectants

Steam Sterilization/ Autoclave

General Information

Waste must not be contaminated with radioisotopes or hazardous chemicals

- For disposal of MPW which contains or is contaminated with radioactive material or hazardous chemicals, refer to the Multihazardous Waste Section
- In accordance with NIH policy, all MPW boxes will be kept inside the lab until they are sealed and removed for disposal to the approved collection area. No MPW boxes are allowed in hallways, common areas, or elevator lobbies

MPW Minimization – Converting MPW to General Waste:

- Examples of MPW which may be converted to general waste through decontamination/inactivation:
 - Liquid clinical specimens (urine, blood)
 - Patient care materials: Towels, absorbent material, or similar materials
 - Cultures and media
- For assistance with decontamination procedures, contact your Safety Officer or technician NIAIRPBaltimoreSafetyOffice@mail.nih.gov
- Suitable chemical disinfectants include:
 - Sodium hypochlorite (bleach at 5.25%), (Mercury Free), 1:10 dilution
 - Wescodyne (NSN-6840-00-526-1129), use according to manufacturer's directions

Always use a disinfectant appropriate to the infectious material you wish to inactivate

- Use autoclavable Biohazard bags imprinted with process indicator: (small: NSN-6530-01-282-6378; medium: NSN-6530-01-142-2255; large: NSN-6530-01-218-4644)
- Place in an autoclaveable pan for transporting and autoclaving
- Add 50 ml water to the autoclave bag BEFORE closing, secure with autoclave tape, but not air-tight
- Waste must be processed for 60 minutes at **minimum** 121° Centigrade
- Cool, discard bag and contents: Use the Disposable Labware & Broken Glass box;
 Don't discard autoclave biohazard bags in the general waste dumpster (place in MPW boxes)

Autoclaves must be maintained to manufacture specification and validated monthly



Continued on next page

Medical Pathological Waste (MPW)

Use MPW Box Kit ONLY for MPW

The MPW Box ("Burn Box")

Lab personnel are responsible for restocking their work spaces with MPW boxes, bags, tape and/or ties. MPW boxes, bags, tape and ties are located in the NIA Medical Pathological Waste (MPW) Holding Area 02B207 for the BRC and room 1906 for Triad. If supplies are low in the restocking areas, please contact the NIA Safety Officer.

The MPW box MUST NOT be used for disposal of general trash such as soda cans, paper, cardboard, bottles, etc., or for storage or moving laboratory equipment, office equipment, or household items The MPW box MUST NOT contain free liquids, or solids, such as ice, that may melt.

Pathological waste (tissues and carcasses) MUST be packaged separately from other MPW to avoid odors and sanitation problems

"Sharps" (needles, syringes, scalpel/razor blades, pipette tips, etc.)

Waste Management Procedures

- Do not recap, bend, remove, or clip needles
- Place intact needles and syringes in the sharps container: (small: NSN-6530-01-196-0284; medium: NSN-6530-00-L03-5923). **Do not use large sharps containers that may not fit in a MPW Box**
- Fill 3/4 full, snap lid closed, and discard container in an MPW box
- Do not attempt to compact contents of containers



Labware

- Chemical decontamination
 - Submerge the labware for 30 minutes in an appropriate disinfectant solution

- Place rinsates into a carboy describing the contents on the waste label, complete all information on waste label
- Discard labware in Disposable Labware & Broken Glass Box
- If glassware/labware cannot be chemically decontaminated, it must be autoclaved to decontaminate

Cell Culture Media or Blood and Body Fluids

- All materials contaminated with agents used at BSL-3 or BSL-2/3 must be packed as MPW after decontamination
- Decontaminate chemically or by autoclaving.
- For chemical decontamination use an appropriate chemical decontaminant following manufacturer's directions
 - Let stand for 30 minutes
 - Decontaminated fluid may be discarded into a sink drain followed by copius amounts of water
 - Dispose of empty decontaminated cell culture vessel in Disposable Labware & Broken Glass box

Solid Media

Autoclave as described above

INSTRUCTIONS FOR PACKAGING REGULATED MEDICAL WASTE BRC &Triad

Step #1-Turn box over and tape the bottom of the box on all seams with a minimum of 2 inch wide, moisture resistant tape. 2 strips for the center seam 1 strip for each of the side seams



Step #2- Turn box upright and insert a red bag. Pull bag gently over the sides.



Step #3- After the bag is full, twist the top of the bag.



Step #4- Double over the top of the bag and cinch or wrap tightly with tape, securing the opening. DO NOT PUSH BAG INTO THE BOX WITH HANDS!!



Step #5- Carefully close the flaps. Waste will be pushed down by the flaps.



Step #6-Tape and securely seal the top of the box with at least 4 strips of 2inch wide moisture resistant tape. 2 strips for the center seam 1 strip for each of the side seams

NIH Recycles: Reduce, Reuse & Recycle

Web Page

Containers

Please Rinse


Do Not Recycle

Green Procurement

General Information - Contact the environmental manager at (443) 740-2761

Check the NIH Recycles web page http://www.nems.nih.gov/Pages/default.aspx,
 http://orf.od.nih.gov/EnvironmentalProtection/WasteDisposal/Pages/recycling.aspx)
 for additional and updated information

• All recycling containers will be identified by the blue and green NIH recycling logo and with information as to the specific material which can be recycled in the container. Call (410) 558-8413 to request additional containers. Personnel are encouraged to create an accumulation area where all office recyclables are prepared and stored for pickup.



• Please rinse food/beverage containers before putting in recycle container

• Material contaminated with food products, infectious material, hazardous chemicals, radioactive materials or empty containers previously containing infectious material, hazardous chemicals, or radioactive materials

• Other materials which are not recyclable: Pyrex glass labware, polystyrene, glass slides, window or sheet glass

For information on Green Purchasing go to: http://orf.od.nih.gov/Environmental+Protection/Green+Purchasing/

What Can I Recycle?

Recycling Info - Call (410) 558-8413



Reduce ~ Reuse ~ Recycle






















(Newspaper, magazines, scientific journals, catalogs, binders, Post-It notes, manila folders, envelopes, tissue and paper towel boxes - no tissues or towels, white or colored paper, frozen food boxes, and all paperboard)

Recycle in All Paper Products bin












(Aluminum cans and foil, all plastic bottles and containers - #1, 2, 3, 4, 5, 6, and 7 - yogurt containers, steel and tin cans, glass bottles and jars, buffer and saline bottles, prescription bottles, food storage bags and containers, plastic utensils and plastic bags)

Recycle in Commingled bins





Pipette Tip Racks and Plastic #5 Recycle in Pipette Tip Rack bin







(computers, monitors, laptops, flash drives, keyboards, memory cards and hard drives) Call your IC personal property services









Construction **Debris**



Wooden Shipping Pallets

ACS Plastic Resin Codes

For UPS Batteries see Chemical Waste Section

















(Non-Styrofoam)

Assistance: 410-558-8413

E-mail: NIAIRPBaltimoreSafetyOffice@mail.nih.gov

General Waste

Material free of any apparent or actual pathological/infectious, radioactive or hazardous chemical contamination. Note: Some laboratory material may be decontaminated and then discarded as general waste.

For Waste Minimization and Pollution Prevention guidance go to: http://orf.od.nih.gov/Environmental+Protection/Waste+Disposal/generalwaste.htm

MOST GENERAL WASTE CAN BE RECYCLED!

Examples of General Waste That Cannot Be Recycled

- Decontaminated media or labware
- Pyrex glassware (other glassware can typically be recycled)
- Uncontaminated animal bedding and PPE
- Food contaminated items that cannot be decontaminated

Materials Which Are NOT General Waste

- •NEVER use an MPW box to dispose of general waste or confidential materials
- Items which contain chemical, radioactive materials or the actual or perceived presence of pathogenic agents
- "Sharps" (needles, syringes, scalpel blades, etc.) see MPW Section
- Empty 5 gallon (or larger) plastic or metal containers, such as those used for solvents or paint see Chemical Waste Section

Office or Lab Waste

Waste Management Procedures

- Reduce, Reuse and Recycle think recycling first before you trash it!
- Strive for ZERO WASTE where possible. For more information go to: http://nems.nih.gov/programs/WM/Pages/Recycling.aspx#Defined

Glass/Plastic Labware

• Place non-recyclable uncontaminated or decontaminated labware in the Disposable Labware & Broken Glass box

- Close box and secure with filament tape
- Glassware/labware that cannot readily be chemically decontaminated should be autoclaved prior to disposal as general waste



Liquid Culture Media

• Before disposal, cell culture media must be decontaminated (see MPW page for instructions) either by steam autoclave or adding disinfectant directly to vessel or treating pooled spent media

- Decontaminated media may be discarded into a sink drain
- Dispose of empty, decontaminated cell culture vessels in the Disposable Labware & Broken Glass box

Solid Media

• Autoclave (see MPW Section), then dispose of the bag and solid media into a Disposable Labware & Broken Glass box

Animal Bedding

• All waste animal bedding is processed through the Dustcontrol system and disposed of through the general waste contractor

• Contaminated PPE from animal bedding is disposed of as MPW; uncontaminated PPE is disposed of as general trash

Note~Some items may not be available for off site facilities

Note~Some items may not	t be available for off site facilities		
Stock Number	Description	Size/Unit	Usage
NSN-8105-00-L04-2610 NSN-6530-01-282-6378	Bag closures, plastic bag ties Bag, biohazard autoclave w/process indicator	12" long small 8" X 12"	Seal bags w/animal carcass/bedding Autoclave MPW/media/labware
* NSN-6530-01-142-2255	Bag, biohazard autoclave w/process indicator	medium 19" X 23"	Autoclave MPW/media/labware
* NSN-6530-01-218-4644	Bag, biohazard autoclave w/process indicator	large 25" X 35"	Autoclave MPW/media/labware
* NSN-8105-00-826-6468	Bag, clear plastic	30" X 40"	Dispose of chemically contaminated solid
NSN-8105-01-195-8730 NSN-8115-00-L04-0680	Bag, clear plastic MPW Box kit	13" X 24"	Collect chemically contaminated solids 10 bags & ties MPW collection and disposal
NSN-8105-41-044-5727	Replacement bags for MPW boxes	5 boxes, 19.5" X 44.5"	Animal carcasses/tissue/bedding
NSN-8115-01-122-1772	Box, disposable labware/broken glass	bench	Disposable labware and broken glass
NSN-8115-01-154-2305	Box, disposable labware/broken glass	floor	Disposable labware and broken glass
NSN-6530-01-294-2865	Container, puncture resistant	small	Collect sharps for disposal
* NSN-6530-01-274-5099	Container, puncture resistant	medium	Collect sharps for disposal
* NSN-7690-00-833-0318	Label, Caution – Radioactive Material tape	roll	Identify radioactive material
NSN-7530-00-L07-2375	Label, Biohazard	1'X 3'	Warning of biohazard material
* NSN-7530-00-L07-2376	Label, Biohazard	2.2" X 3.5"	Warning of biohazard material
* NSN-8135-01-025-2532	Pads, absorbent paper	18" X 20"	Absorb residual liquids
Call DEP, 301-496-7990	Sodium hypochlorite (Mercury Free bleach)	1 gal	Disinfect/inactivate
NSN-6840-00-526-1129	Wescodyne povidine-iodine based solution	bottle	Disinfect/inactivate pathogen(s)
NSN-7530-00-L07-5985	Tag, Chemical Waste	pack of 10	Identify chemical waste
NSN-7530-00-L07-8835	Tag, Radioactive Waste Pick-up Receipt	pack	Identify radioactive waste
NSN-7510-00-290-8036	Tape, filament	roll	Close waste bags/seal boxes
* Safety Provides Available from Radioact	ive Waste Service (301) 496-4451	• • • • • • • • • • • • • • • • • • • •	
Description		Size/Unit	Usage
Stepcan		One size	Collect solid radioactive waste
Carboy plastic container		2/5 gallon	Collect aqueous radioactive waste
Mixed waste container		4/10/20 liter	Collect liquid mixed waste
Available from Chemica Solvent safety cans	I Waste Disposal Service(410) 558-8413	3/5 gallon	Collect flammable chemical waste
Liquid waste container		3/5 gallon	Collect chemical waste
Plastic waste pail		5 gallon	Collect solid gels
Funnel with lid closure		3/5 gallon containe	
Secondary containment pan rectangular		18" X 26"	Collect spills and overfills
Secondary containment pan round		17" diameter	Collect spills and overfills
MPW and Broken Glassware boxes, filament tape and bag ties Empty chemical bottle tote rectangular		19"x16"x15.5"	Collect empty chemical bottles
Empty chemical bottle tote rectangular		19.5"x15.5"x13"	Collect empty chemical bottles
	Empty chemical bottle tote rectangular		Collect empty chemical bottles
• • • • • • • • • • • • • • • • •	g Service (301) 402-6349	15.25"x11"x19.9"	
Interior metal collection container for recycling "All Paper Products"		37" X 15" X 15"	Collect all paper products, for corridors or office suites
Interior metal collection container for recycling "Commingled Materials"		37" X 15" X 15"	Collect commingled materials, for corridors or office suites
Interior metal collection container for recycling "Toner/Ink Jet Cartridges"		37" X 15" X 15"	Collect Toner/Ink Jet, copier cartridges, for corridors or office suites
Interior metal collection container for recycling "Pipette Tip Racks"		37" X 15" X 15"	Collect pipette tip racks
Small desktop contain for paper recycling		12" X 9" X 6"	Collect all paper products
Large cardboard collection container for paper recycling in copy rooms		30" X 24" X 20"	Collect all paper products
30 cubic yard dumpster for construction debris recycling		30 yard open dumpster	Collected mixed construction debris for
Hamper for office clean out		dumpster	building renovation projects Collect all paper products from office clean out